



ULTRARAY
RADIATION PROTECTION

Lead Glass

Ultraray Radiation Protection supplies Leaded X-Ray Glass and Frames for viewing windows, control booths and mobile shields.

Key Features:

- Optically Clear – Not Yellow
- Easy to Cut – Not Soft
- Does not discolour after exposure
- Professional custom crating for worldwide drop shipments
- Optional Laminated Safety
- Optional Non Lead for Mammography



Cleaning Instructions

Lead glass is more susceptible to staining compared to normal window glass. Pay attention to the following precautions for installation and cleaning.

- Polish the surface with a clean dry cloth (like gauze) using alcohol
- Use a clean dry cloth to remove alcohol from the surface
- **DO NOT USE A WET CLOTH OR WATER**

